

INSTRUÇÕES PARA TROCA DO CABO DE SAÍDA

JET-POWER HORIZONTAL SÉRIE 2000A

1. Desenrolar os cabos de entrada e saída
2. Abrir a tampa superior e a lateral direita (lado do cabo de saída).
3. Soltar a abraçadeira que prende o cabo de saída.
4. Retirar os parafusos que fixam os terminais positivo e negativo.
5. Puxar o cabo para fora (acertar as borrachas de passagem se soltarem na retirada do cabo).
6. Colocar o novo cabo observando na plaqueta as polaridades de cada um (o maior é o positivo).
7. Fixar os terminais e as abraçadeiras.
8. Fechar a tampa e enrolar os cabos nos suportes.

INSTRUCTIONS TO EXCHANGE OUTPUT CABLES

JET - POWER SERIES 2000A

1. Unroll the input and output cables.
2. Open the upper and right covers (The right cover is by the side of the output cable).
3. Release the brace that holds the output cable.
4. Take out the screws that hold the negative and positive terminals.
5. Pull off the cable (Put right the passage rubbers if they come out).
6. Put the new cable watching the polarity (the bigger cable is positive).
7. Stick the terminals and the braces.
8. Close the cover and roll the cables in the support.